

Sweep Boxing Instructions – 5 pair

Materials Needed	Procedure Overview
<ul style="list-style-type: none">• Tape dispenser	<ul style="list-style-type: none">• Assemble sweep box• Bundle oars and cover blades• Protect blades and shafts with cardboard• Tape box closed

Procedure

Important Note: For this sweep boxing procedure, you will receive two packages from us. The first package is a flattened sweep box to be used in step 1. The second box contains foam blade bags and a single cardboard sheet. This box and its contents will be used for this procedure. **DO NOT break down this box or discard the cardboard sheet. You will need it.**

1. Assemble the sweep box.
2. Cover each blade with a foam bag. Bundle five oars together, alternating the blades (port, starboard, port, starboard). Tape blades together to keep foam bags secure.
See photo A.
Tape handles together.
3. Repeat step 2 for the remaining five oars. You should have two bundles of oars. Put the bundles in the sweep box in opposite directions.
See photo B.
4. The box that contained the foam bags will be used to protect the blades. Use one half of the box to cover five blades and the other half to cover the remaining five blades. This may be a tight fit and that's okay.
See photo C.
5. Use the cardboard sheet to cover the shafts as shown. Tape the cardboard inserts to the exterior box to prevent them from moving in transit. Insert the parts bag between shafts.
See photo D.



photo A



photo B



photo C



photo D